

Operation:

For safe and effective use of the Joye 510 E-Cigarette and its supporting products, please read through the following information carefully before use and follow the standard operating procedures strictly.

The Joye 510 E-Cigarette consists of a power supply with a manual switch (battery), atomization chamber, and a cartridge. The cartridge is suited for one time use only but most people re-fill them with success. New cartridges will always work the best. We recommend keeping a good stock of them handy. When you push the manual switch the Joye 510 will be activated.

Use:

Unpack the cartridge and remove the cover. Click the cartridge in the atomizer. Screw a power supply on the atomizer. Your Joye 510 is now ready for use. Push the manual button for no longer than 5 seconds to avoid overheating of the atomizer. Do not use the Joye 510 E-Cigarette in a vertical position, since liquid could leak. In case the Joye 510 should vaporize continuously or in case the Joye 510 shows signs of over heating, stop the usage, unscrew all parts and contact eciggExpress.com.

Cartridge replacement/filling:

If during the use of this unit, vapor is found to be significantly reduced, the cartridge needs to be replaced or filled with e-liquid/e-juice. To fill a cartridge, simply place between 8 and 12 drops of e-liquid/e-juice into the "wick end" of the cartridge opening. The same applies to filling a new empty cartridge.

Power (battery) supply replacement:

The Joye 510 E-Cigarette power supply needs to be recharged when the unit produces no more vapor.

The Joye 510 E-Cigarette does not cause harm to surrounding people and environment. We recommend however out of courtesy to ask for permission to use the vaporizing function in public places, beforehand. The atomizer does not need to be cleaned with water. However, if you should encounter persisting mal performance you can try to rinse the atomizer with water and by blowing the water through the atomizer several times. The atomizer should be dried with a hairdryer after this process. When the atomizer is fully dry, insert a new cartridge, place the unit vertically and let the liquid penetrate the atomizer for a few minutes. It helps to drop a small amount of liquid directly onto the atomizer to kick start it in case the atomizer is still too dry.

Power supply life:

Joye 510 E-Cigarette power supply function for max 200 to 250 puffs per charge. The Power supply can be charged and used 200 times. After more than 200 charging and usage cycles, their functioning span lessens significantly.

Charging power supply:

Screw the dedicated Power supply in the charger. Connect the charger to the power outlet. 1. The first charge should be kept for 8 hours, even if the LED light turns green. 2. Use for 20 minutes. 3. Charge the Power supply for another 1 hour. Your Power supply is now ready for normal use. Normal charging time should be kept for 1 hour (even if the LED light turns green). Do not use the charger in damp areas. Do not charge the Power supply near a high-temp heat source. Do not weld or pierce the Power supply. If the Power supply is found to be emitting any odor or heat or be discolored or deformed or have any abnormality during charging, please cut off the power source immediately and remove the Power supply from the Joye 510 body or charger and suspend the use of it. The Joye 510 charger can only be used with the Joye 510 dedicated Power supply. Do not try to use this charger to charge other kinds of Power supply. Please keep the Joye 510 and its components and cartridges from the reach of children or animals.

Optional USB charger or universal charger:

Screw the dedicated Power supply in the optional USB charger cable. Insert the USB charger cable into the USB port of your computer, USB Home Charger, USB car charger. Do not charge Power supply outdoors or in a damp environment. Keep all parts out of children's reach.

Structure:

The body is an integrated stainless steel shell structure, containing a Power supply, a manual switch, an atomization chamber and a cartridge.

Caution:

We do not accept any warranty/indemnity claims in case of wrong usage. If you are carrying the Joye 510 with you, please carry it separately in order to avoid scratches or damage due to collision with other parts such as keys or mobile phones. The use of any un-dedicated components will lead to malfunction and damage of this product. The use of other than Joye 510 E-Cigarette cartridges or the use of some liquids can damage the atomizer beyond repair. Please dispose of old Power supply in your local Power supply recycling collection point. When driving, please ensure your strict compliance with the relevant laws and regulations of the country or region where you are staying. Be concentrated on driving and pay attention to road conditions. Do not use this device while driving and secure all parts to avoid damage to the product caused by collision. The Joye 510 uses an advanced microelectronic technology to vaporize a special designed GRAS (generally recommended as safe) approved liquid that is contained in cartridges that are inserted into an atomizer.

Storage:

The Joye 510 E-Cigarette and its supporting parts should be kept away from children's reach and stored safely in a non-damp environment. E-Cigarettes are ADULT DEVICES and are never to be left where anyone under the age of 18 can reach them.

Preparation:

Leave the atomizer without cartridge to dry for the night by storing the atomizer vertically on a paper tissue or dry rack. Charge your Power supply at night.

Maintenance:

The Joye 510 should be maintained regularly.

Clean the screws threads of the different parts such as atomizer, chargers and Power supply with a tissue dipped in purified unperfumed alcohol (please refer to your local drugstore). Clean screw thread will provide better electric conduction. Blow into the atomizer once and a while to evacuate left over liquid. Remove cartridge at night. Put the atomizer to dry for the night on a dry rack. When the vapor diminishes significantly the Power supply needs to be charged.

Power supply and charger: The Joye 510 E-Cigarette is powered by a 3.7 V special Power supply. The charger is specially adapted for the Joye 510 Power supply. The input voltage of the USB home charger is AC100V-240V 50/60Hz. The input voltage of the USB car charger is DC12V-24V. The input voltage of the USB Power supply computer charger is DC5V. Pay attention to the value of the local voltage to be in accordance to that of the Joye 510 charger